## V82 Watch (SeTracker) User Manual

Please read this manual carefully before starting to use the watch, pictures for reference only.


## 1.Preparation

- 1.1. Check if the watch is of the correct model and has complete accessories (1\*watch, 1\*USB cable for recharge, 1 user manual, 1 screwdriver).
- 1.2. Prepare a GSM Micro Sim card and activate data flow, GPRS and caller display function.

#### 1.3. Insert Micro Sim Card

Turn off the watch before inserting the SIM card.

Open the cover at the side of the watch and find the sim slot. Insert Sim card into watch, with metal upside and gap facing inside, as per the picture.



#### 1.4. Install the APP "SeTracker"

Please follow the instructions at the last page of this manual.

#### 2.Product function

- GPS+ LBS+AGPS+WIFI real-time location on Map
- Two way phone calls
- Intercom
- Health
- Footprint
- Geofence
- Alarm clock
- "SOS emergency" alarm
- "Low power" alarm
- Remote shutdown

## 3. Watch introduction and Screen display




# 4. APP (SeTracker) C 'de

## 4.1. Account Registration


After installation of APP, you need to register an account to monitor the watch.

Select Language and Area based on actual situation and click "register" to enter registration page. Scan or input the watch ID on the barcode (usually on watch box), input APP account name, device nick name, parent phone number and login password to complete registration.



## 4.2. Login and Start Experiencing the Functions

After registration, log in the account to experience the functions.



**4.2.1. Intercom:** two way voice message (max 15s) and one way text message (Max 15 Characters).

Voice message: Click "start record" to begin recording, click "stop record" to finish and send the message to watch. The APP will receive notification for the voice message (The time of receipt depends on the network conditions). Voice message received can be played repeatedly.

Text message: Change the input method from voice to text. Click send after message is generated.






## **4.2.2. Map:** real-time locating of the watch

Both watch location and APP cell phone location are displayed on map. Click "Locate" to perform the real-time locating for 3 minutes (interval time for location information uploading:10s) . The watch will restore to the default work mode 3 min later.

The two locating mode are differentiated by colors: GPS mode (Red), LBS mode(Blue).

#### 4.2.3. Health



#### (a) Walk, Amount of Exercise, Journey

Equipped with a 3D sensor, the watch can count steps (walk) of watch users and calculate the corresponding distance (journey) and calorie consumption (amount of exercise).

Note: Default setting of this function is off, click "Walk-switch" to switch on. Adjust the steps and weight of watch users to improve the accuracy of calculation.

## (b)Turnover of sleep


Judgment of the watch user's sleep quality can be made based on the turning frequency.

Note: Default setting of this function is off, click "Walk-switch" to switch on and set the time for calculation.

## 4.2.4. Footprint

The historical route of watch can be replayed with selected date and time.

## 4.2.5. Settings:




## • SOS/The family number

Up to 3 numbers can be set as SOS family numbers. When watch user makes SOS emergency call, monitor phone will receive alert message. Watch will make circular calls to the 3 numbers in turns for 2 rounds until someone answers the call. If nobody answers the call after 2 rounds dialing, SMS message will be sent to monitor number (default "off).



#### Voice

Input guardian's phone number and click "ok" to send remote monitoring instructions. After getting the command, watch will dial the monitor number automatically. When the cell phone answers the call from watch, guardian is able to hear the watch user's surroundings, while the watch user cannot hear sound from the mobile phone.




#### Work mode

Three basic work modes with different upload interval can be chosen.

## No disturbing

All incoming calls will be shielded during this time.



#### SMS alerts setting

Set to send SMS message to cell phone under the following circumstances:


a) watch battery is low (low-voltage)

If switched on, when the remaining battery of watch (shown in percentage) reaches below 20%, the watch will send alert message to monitor number (default "off").

b) watch user uses SOS function (SOS remind)

If switched on, the watch will send alert message to monitor number (default "off") if the SOS call was not answered.

Please refer to the SOS function.



#### Contacts

10 phone numbers can be set and allowed to call the watch. But the watch can just pick up calls from these numbers and cannot call these 10 numbers.

#### Telephone

Preset up to 10 phone numbers with names, which will be displayed in the watch's phone book. Two-way phone call between the watch and the preset phone numbers is allowed.

#### • Language and time zone

Set language and time zone based on the watch user's location. Time and date on watch display will update automatically.

#### · Push the switch

Enable or disable the switch of "take off the watch" to get alert message or not.

## • LBS switch

Turn on (or turn off) the "LBS switch" to enable (or disable) LBS locating method.

#### Remote shutdown

Shut down the watch remotely with the sim installed in watch.

#### Restore the default work mode

Under default work mode, GPS is opened 24 hours with 10 minutes upload interval.

#### 4.2.6. Geofence:


Preset the safe area by selecting the centre point and the radius (Minimum 500meters). Alert messages will be sent to APP message center when watch user goes out of the fence.

#### 4.2.7. Message Center

Click "Message" to enter and view the list of all alert messages details including SOS alert, take off watch alert, exit geofence alert etc.

#### 4.2.8. Alarm

Up to 3 sets of alarm clocks can be preset.






**4.2.9 Watch:** Click "Watch" to send the command which will instruct the watch to ring for 1 minute. Press any key on watch to stop the ring.

## 4.2.10. "MY" menu

To edit personal data, add/delete device or change the password.

Note: more than 1 watch can be monitored under one account.





# 5. Watch Operation Guide

#### 5.1. Turn on/off the watch

Long press the power button to turn on the watch with or without sim installed.

Long press the power button to turn off the watch when sim card not uninstalled.

Click "Setting-Remote shutdown" on APP to turn off the watch with sim card installed.

The watch will automatically shut down when it is powered off.

## 5.2. SOS emergency call

Long press phone button to initiate the emergency call and to send alert message to monitor phone number. The watch will circular dial 3 preset SOS numbers until the call is answered. After 2 turns, if nobody answers the call, watch will send message to monitor number (default "off").

#### 5.3. Dial family number

Long press button 1 to dial SOS/family number 1, long press button 2 to dial SOS/family number 2.

## 5.4. Answer calls or hang up

Short press phone button to answer incoming calls.

Short press power button to hang up calls.

While receiving calls, press power button or phone button to adjust the volume.

#### 5.5. Phone book

Short press phone button to enter phone book, press phone button again to select number, and then long press phone button to dial. Numbers in the phonebook needs to be preset via APP under "Settings-telephone". The watch number and the numbers listed in the phone book can call each other.

#### 5.6. Intercom

Long press the power button to start recording and release the button to send the voice message to APP.

Short press the power button on watch to play the voice message or text message after the watch receives it. The message will be deleted after played.

## 6. Troubleshooting

If the watch fails to connect to the server and display disconnection on APP when turned on for the first time. Please confirm:

- (1) The sim card is properly installed and screen display is normal;
- (2) The sim card is GSM sim, please note CDMA sim card is not supported;
- (3) The sim card has activated 2G data traffic and have sufficient credit;
- (4) The parameters including ID, IP and port of the watch are correct.

Send SMS message "pw,123456,ts#" from cell phone to watch. Then the watch will reply its parameters in returned SMS. Make sure the watch is turned on with SIM card installed and the SMS message was edited under English input method. Any further questions, please contact your supplier.

## 7. APP Download

Scan the QR code below to download Android or IOS APP. or download "SeTracker" directly from the App Store (IOS) and Google Play Store (Android).

